Use of the pause command

IW		Robot

{RUN 9} →

Move robot along route 9

← {ACK 9}

{PAU 9} →

Immediately stop robot

← {ACK 9}

{CNT 9} →

Carry on moving along route 9

← {ACK 9}

{PAU 9} →

Immediately stop robot

← {ACK 9}

{INI 9} →

Move robot back to start of route 9
and run route 9 from the start

← {ACK 9}

← {RDY 9 OK 0 OK}

{ACK 9} →

{RUN 9} →